

TRANSCEIVER

After the battery is full charged

Turn on the Radio,
Message "FREQUENCY MODE"

Enter the desired frequency
By Example Key in 1 6 0 1 0 0

Turn OFF the Transceiver

Turn ON the Transceiver
The 160000 is set.

NOTE initial Mode selection

Press and HOLD the Menu button and turn on the Radio
Frequency MODE or "TELL MODE" message will come up,
Repeat the operation to set the radio in
"FREQUENCY MODE"



RECEIVER

Before you apply power,
1 connect the Antenna,
2 insert the Microphone
3 Power the radio ON

4 On the Microphone keypad click on the **A/B button**
Move the arrow to the upper section of the display

Key in the frequency by example 1 6 0 1 0 0

Turn the Power OFF
Turn the Power ON
Your selected frequency will appear at the top of the display
Turn the Power OFF
Remove the Microphone.

System is Ready

